



# Cab Liner Installation

## Front Door Center and Rear Door on Right

Please read all instructions prior to installation.

The installation of Door Guard's elevator cab liner requires only the ratchet tool provided. Successful installation requires placing each section in the elevator in proper sequence as described below. Keep sections folded until they are placed inside the elevator cab. All components are customized for a specific elevator and individually labeled. **Many components are labeled for the "left" and "right" side of the cab. Your orientation for the Front Button Panels and Left and Right Wall Liners will be when you are inside the cab facing the lobby entrance. Your orientation for the Rear Button Panels only will be when you are inside the cab facing the rear door (see Elevator Cab Configuration on Page 2).**

### Step 1 Front Button Panels & Header

- A. Position the Right Front Button Panel, Left Front Button Panel and Interior Front Header on the inside of the elevator. Lean both Left and Right Front Button Panels against the interior jambs/COP. Be sure the Locking Plates are disengaged per Step 1 of the Locking Plate Instructions.
- B. Slide the Interior Front Header over the top of the Left and Right Front Button Panels. Position the Left Front Button Panel firmly against the interior jamb/COP. Position the Right Front Button Panel firmly against the interior jamb/COP. Engage the Locking Plates per Steps 2 and 3 of the Locking Plate Instructions.

### Step 2 Left Side Wall Liner

Place the Left Side Wall Liner inside the cab while still folded. Be sure the Locking Plates are disengaged per Step 1 of the Locking Plate Instructions. Unfold the Left Side Wall Liner and position it against the left cab wall with the Locking Plates against the Left Front Button Panel. If provided, install Left Side Wall Stabilizer on the top edge of the wall panel. **If you have a split wall, install the Left Bottom panel first and the Left Top panel second.**

### Step 3 Rear Button Panel & Header

Position the Left Rear Button Panel and Interior Rear Header inside the elevator (while facing the rear door). Lean the Left Rear Button Panel against the interior jambs/COP. Be sure the Locking Plates are disengaged per Step 1 of the Locking Plate instructions. Slide the Interior Rear Header over the top of the Left Wall Liner and the Left Rear Button Panel. Position the Left Rear Button Panel firmly against the interior jamb/COP.

### Step 4 Engage Locking Plates

Engage the Locking Plates per Steps 2 and 3 of the Locking Plate instructions in the following order: Left Rear Button Panel, and Left Side Wall.


## Step 5 Right Side Wall Liner

- A. Place the Right Side Wall Liner inside the cab while still folded. Be sure the Locking Plates are disengaged per Step 1 of the Locking Plate Instructions.
- B. Unfold the Right Side Wall Liner and position it against the right cab wall with the end of the panel against the Left Rear Button Panel. If provided, install Right Side Wall Stabilizer on the top edge of the wall panel. Engage the Locking Plates per Steps 2 and 3 of the Locking Plate instructions. **If you have a split wall, install the Left Bottom panel first and the Left Top panel second.**

**NOTE:** Upon installation of side walls, you will note approximately a 1 inch gap between the side wall and either the button panel or rear wall adjacent to the locking plate. This 1 inch gap is designed to facilitate installation and de-installation of the Cab Liner.

***If ordered, you are now ready to install the three-piece Door Liner using the enclosed installation instructions.***

### Elevator Cab Configuration



**NOTE:** Each Door Guard Cab Liner is fabricated to the exact cab dimensions and configuration of the elevator for which it was intended. This Cab Liner can only be used in elevators with the exact same model configuration and dimensions. Do not attempt to use your Cab Liner in an elevator using a different dimensional "foot print" as it will not protect the elevator interior as intended and you may damage your Cab Liner.

We strongly recommend storage of your panels in a vertical or horizontal position. **TO PREVENT BOWING, DO NOT LEAN PANELS AGAINST WALLS.** Panels should be stored at temperatures between 60 and 80 degrees Fahrenheit.

### WARRANTY

One (1) year manufacturer's warranty indicating both cab liner and door liner is free of defects in material and workmanship. Warranty will not cover normal wear and tear, damage incurred during transportation, installation, de-installation, nor Locking Plate compression exceeding 70 pounds, or if not stored in accordance with manufacturer's recommendations as described in all installation instruction sheets. Unauthorized modifications will nullify the warranty.

**Door Guard Inc., Pittsburgh, PA 15205**  
**Phone 724 695 8936, Fax 724 695 8937**  
**email: [sales@doorguardinc.com](mailto:sales@doorguardinc.com)**  
**Website: [www.doorguardinc.com](http://www.doorguardinc.com)**  
**U.S. Patent 61366251**